



FASTEN THE SCREWS THROUGH THE WASHERS AND INTO THE HANDLE.
ADJUST THE HANDLE TO ALIGN IT WITH YOUR REMAINING FRONTS.